


TECKNET

Wireless Mouse



Model: EWM01832

USER MANUAL

EN


DE

FR


ES

IT

Package Contents



Product Diagram



EN

- ① Scroll Wheel
- ② Right button
- ③ DPI button
- ④ Left button
- ⑤ Forward button
- ⑥ Back button
- ⑦ Pairing button
- ⑧ On/Off Button
- ⑨ Nano receiver

DE

- ① Scrollrad
- ② Rechte Taste
- ③ DPI-Taste
- ④ Zurück-Taste
- ⑤ Vorwärts-Taste
- ⑥ Linke Taste
- ⑦ Pairing-Taste
- ⑧ Ein / Aus-Taste
- ⑨ Nano-Empfänger

FR

- ① Molette de défilement
- ② Bouton droit
- ③ Bouton DPI
- ④ Bouton gauche
- ⑤ Bouton avancer
- ⑥ Bouton retour
- ⑦ Bouton association
- ⑧ Bouton On/Off
- ⑨ Récepteur Nano

ES

- ① Rueda de desplazamiento
- ② Botón derecho
- ③ Botón DPI
- ④ Botón izquierdo
- ⑤ Botón de avance
- ⑥ Botón de retroceso
- ⑦ Botón de emparejamiento
- ⑧ Botón de encendido/apagado
- ⑨ Receptor Nano

IT

- | | | |
|----------------|-----------------------|----------------|
| ① Rotellina | ⑤ Tasto Sinistro | ⑨ Tasto On/Off |
| ② Scorrimento | ⑥ Tasto Avanti | Ricevitore |
| ③ Tasto Destro | ⑦ Tasto Indietro | Nano |
| ④ Tasto DPI | ⑧ Tasto Accoppiamento | |

FCC STATEMENT

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

IMPORTANT SAFETY INSTRUCTIONS-CAREFULLY FOLLOW THESE INSTRUCTIONS.



1. SAVE THESE INSTRUCTIONS - This sheet contains important safety and operating instructions.



2. Before using the product, read all instructions and caution markings on the product, accessories and device using our product.



3. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.



4. Children should be supervised to ensure that they do not play with the appliance.



5. Keep the product away from fire or explosion may occur.



6. For proper insertion, please observe polarity indicators (+/ -)

7. Remove the batteries if the product is not going to be used for a long period of time.



8. Do not place product in or near inflammable, explosive or hazardous object.

9. Do not place in or near water, rain, excess moisture or extreme heat.

10. Do not operate product if it has been damaged in any way.
11. Do not disassemble the product. Disassembly may result in a risk of safety hazards.
12. Do not throw or shake the product.

Correct Disposal of This Product

(Waste Electrical & Electronic Equipment)



This Marking shown on the product or its literature, indicate that it should not be disposed with other household wastes at the end of its working life.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources. Household user should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

Product Specification

Working voltage:	DC 1.5V
Working current:	10mA
Working distance:	10m
Number of keys:	6 keys
Operating system:	Windows XP / Vista / 7 / 8 / 10, Mac OS X / Linux / Android
Transmission Power:	0.25 dBm

Main Features

1. Uses the latest version of Bluetooth 5.0 + Bluetooth 3.0 + 2.4G three-mode technology, strong Bluetooth compatibility, fast connection speed, you can fully enjoy wireless space.
2. Bluetooth supports multiple channels, can connect multiple devices and easily switch between.
3. 3 adjustable DPI Levels: 1000-1600-2400.
4. Use any key to wake-up the mouse while in sleeping mode.
5. Power on/off button for complete battery shutdown for better power saving
6. Lower power consumption, High sensitivity, multi-level sleep-mode.

Instructions

In the 2.4G wireless mode, the LED indicator is green and in the Bluetooth mode it is blue.

2.4G wireless mode

1. Insert one AA battery into the mouse noting the correct polarity
2. Toggle the switch to select the 2.4G wireless mode and plug the Nano USB receiver into the USB port of your device.
3. Press any mouse button to confirm the connection is successful.

Note: Make sure the Nano receiver and mouse are within 1M range when connecting for the first time.

Bluetooth mode

1. Insert one AA battery into the mouse noting the correct polarity
2. Toggle the switch to select the Bluetooth mode. Long press the Bluetooth pairing button at the bottom for 3 seconds to enable pairing while the LED indicator is flashing.

Note: The first time this bluetooth mouse is connected to you device, the LED indicator will continuously flash, the bluetooth will turn off automatically if no device is connected within 2 minutes.

3. Turn on the computer's Bluetooth and search for new Bluetooth devices [BM20X] and then connect.

Use tips

1. DPI adjustment:

Click the DPI switch button at the top of the mouse to change the DPI level between 1000-1600-2400. The first time the mouse is connected, the default DPI is 1000. The mouse will remember the last DPI selection when switch DPI levels every time. When switching DPI levels, the mouse's transparent scroll wheel flashes once when switching to 1000 DPI, flashes twice when switching to 1600 DPI, and flashes three times when switching to 2400 DPI.

2. Battery replacement reminder:

While using the mouse, if the transparent scroll wheel flashes blue or green, please replace the battery.

3. Automatic sleep and manual shutdown:

1. This mouse will enter sleep mode after 30 minutes of inactivity. Press any key to wake it up. Turn off the power button or remove the Nano USB receiver, the mouse will enter the power-saving shutdown status.
2. If you take the mouse outdoors or don't use it for a long time, please set the power switch on the bottom of the mouse to "Off"

4. Reconnect:

If other abnormal interruptions occur, please repeat the above method to reconnect.

In the device management window of the Bluetooth device driver, select the name of the mouse driver to be deleted, and click the "Delete / Uninstall" option to delete the Bluetooth device.

Troubleshooting Guides

If the Bluetooth mouse fails to connect to your computer or does not work properly, try the following steps:

1. Please use a quality branded Bluetooth adapter, otherwise it may cause compatibility problems and affect the normal use of the mouse
2. Before making a mouse connection, make sure that you have completed the installation of the Bluetooth adapter and the computer's Bluetooth function is working properly.
3. Make sure the mouse is working and is within the range of 10m.
4. Make sure that the computer's Bluetooth device has not changed. If it changes, it must be reconnected
5. If your computer's Bluetooth is also connected to another Bluetooth device, check whether the speed of the computer's Bluetooth is sufficient.
6. Check the battery. If it is out of power, replace the battery.

Wireless 2.4G

Reconnect:

The wireless mouse signal has a built-in identification code for transmitting and receiving, which is convenient for one-to-one use when using multiple groups of mice. High temperature, high magnetic field, vibration, etc. may make this code disappear, and you need to reconnect before you can use it.

1. The battery on the mouse switches to 2.4G mode, and the green light flashes.
2. Press and hold the left /middle / right three keys at the same time (for 3 seconds) to enter the 2.4G pairing and the LED flashes quickly (the pairing time is 20 seconds).
3. Insert USB Dongle within 20 seconds.
4. 2.4G pairing is successful when LED lights up for 2 seconds.

SIMPLIFIED EU DECLARATION OF CONFORMITY

Hereby, Shenzhen Unichain Technology Co., Ltd. declares that the product type EWM01832 is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address: <https://eu.tecknetonline.com/>